

IJ-25 – Changing the Default Postage Value from \$0.39 to \$0.41



Preset Postage Setting:

The Preset Postage Setting allows the user to determine the default postage value that is displayed each time the meter is powered on or returns from Locked mode.

<p>1</p>	<p>If the meter shows last years rate after installing the new rate card, then the Preset Postage Value has to be changed.</p> <p>From the main screen press the Menu button.</p>	
<p>2</p>	<p>Press the left Blue or Red button until you see the "Setup" function.</p> <p>Then press the OK button.</p>	
<p>3</p>	<p>Press the left Blue or Red button until you see the "Preset Postage" function.</p> <p>Then press the OK button.</p>	
<p>4</p>	<p>The postage value will be blinking. Enter the new postage value that you use most often. Then press OK.</p> <p>Note: For 0.41 enter the numbers 41 and press OK.</p> <p>Note: If an incorrect value is entered, press "C" and start again.</p>	
<p>5</p>	<p>Press the C button until you get to the Ready screen.</p> <p>Note: In order for the new Preset Postage to take effect, unplug the power cord and plug it back in to restart the meter.</p>	